



INSTALLATION INSTRUCTIONS



COMPONENT: REAR RESERVOIR SHIELDS (KING 3.0)

PART #: 58880

FITS: 2008-2020 TOYOTA LAND CRUISER 200 SERIES

PARTS LIST:

ITEM #	PART #	QTY	ITEM DESCRIPTION
1	58881L	1	3.0 REAR RESERVOIR SHIELD: LEFT
2	58881R	1	3.0 REAR RESERVOIR SHIELD: RIGHT

REQUIRED TOOLS

- 12mm Wrench

IMPORTANT

- These reservoir shields are only compatible with King 3.0 rear shocks.

STEP 1

Remove both bolts that secure the emergency brake cable using a 12mm wrench or socket.



STEP 2

Leaving the stock emergency brake tabs against the frame, re-use the stock bolts and insert them through the holes in the reservoir guard. Re-tighten the hardware to 25 ft/lbs.



RESERVOIR SHIELD INSTALLATION IS NOW COMPLETE!



FOR INSTALL QUESTIONS OR CUSTOMER SERVICE INQUIRIES:

Call 951.737.9682 or email info@chaosfab.com