
### TOTAL CHAOS FABRICATION

#### INSTALLATION INSTRUCTIONS

05+ TACOMA PRERUNNER/4WD LONG TRAVEL 03+ 4RUNNER/07+ FJ CRUISER LONG TRAVEL 86000HLT

DATE: 3/6/2009 REV.: 01 SCALE: N.T.S. PAGE: 1 OF 7 DRAWN: SW




#### TOTAL CHAOS FABRICATION www.chaosfab.com

#### INSTALLATION INSTRUCTIONS

05+ TACOMA PRERUNNER/4WD LONG TRAVEL 03+ 4RUNNER/07+ FJ CRUISER LONG TRAVEL

#### 86000HLT

DATE: 3/6/2009 REV.: 01 SCALE: N.T.S. PAGE: 2 OF 7 **DRAWN: SW** 




# TOTAL CHAOS FABRICATION www.chaosfab.com

#### INSTALLATION INSTRUCTIONS

05+ TACOMA PRERUNNER/4WD LONG TRAVEL 03+ 4RUNNER/07+ FJ CRUISER LONG TRAVEL

#### 86000HLT

DATE: 3/6/2009 REV.: 01 SCALE: N.T.S. PAGE: 3 OF 7 DRAWN: SW



# TOTAL CHAOS FABRICATION www.chaosfab.com

#### INSTALLATION INSTRUCTIONS

05+ TACOMA PRERUNNER/4WD LONG TRAVEL 03+ 4RUNNER/07+ FJ CRUISER LONG TRAVEL

#### 86000HLT

DATE: 3/6/2009 REV.: 01 SCALE: N.T.S. PAGE: 4 OF 7 DRAWN: SW

### UPPER CONTROL ARM ATTACHMENT

\*\*\*\* The heims are assembled and preset to TC specifications. Additional adjustments can be made to modify camber or caster. TC does not recommend that the heim be unthreaded more than 1/4" from its present location.

FACTORY NUT

IMPORTANT NOTE:

During assembly, upper &

lower spacers are specific.
Failure to follow these

instructions will result in

damage of all components.

Upper spacer has 9/16" hole

Lower spacer has 3/4" hole

21

18

20

SPINDLE

23

PROPRIETARY AND CONFIDENTIAL
THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE
PROPERTY OF TOTAL CHAOS FABRICATION. ANY REPRODUCTION
IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF

TOTAL CHAOS FABRICATION IS PROHIBITED.

**FACTORY BOLT** 

\*LEFT SIDE OF TRUCK SHOWN. SOME ITEMS NOT SHOWN FOR CLARITY


## TOTAL CHAOS FABRICATION

#### INSTALLATION INSTRUCTIONS

05+ TACOMA PRERUNNER/4WD LONG TRAVEL 03+ 4RUNNER/07+ FJ CRUISER LONG TRAVEL

#### 86000HLT

DATE: 3/6/2009
REV.: 01
SCALE: N.T.S.
PAGE: 5 OF 7
DRAWN: SW




## TOTAL CHAOS FABRICATION

#### INSTALLATION INSTRUCTIONS

05+ TACOMA PRERUNNER/4WD LONG TRAVEL 03+ 4RUNNER/07+ FJ CRUISER LONG TRAVEL 86000HLT

DATE: 3/6/2009 REV.: 01 SCALE: N.T.S. PAGE: 6 OF 7 DRAWN: SW





#### INSTALLATION INSTRUCTIONS

05+ TACOMA PRERUNNER/4WD LONG TRAVEL 03+ 4RUNNER/07+ FJ CRUISER LONG TRAVEL

#### 86000HLT

DATE: 3/6/2009 REV.: 01 SCALE: N.T.S. PAGE: 7 OF 7 DRAWN: SW

#### **INSTALLATION NOTES**

The factory manual is required for torque specifications on all hardware. This procedure will involve the removal and re-installation of many parts. Always use factory replacements for worn or damaged parts. Always use new cotter keys during re-installation.

Some items are not shown for clarity.

In order to retain 4 wheel drive, new axles must be purchased from Total Chaos. Please call for more information.

\*\*\*IMPORTANT INFORMATION\*\*\*
4WD TRUCKS CANNOT BE DRIVEN WITHOUT AXLES INSTALLED!

Page 4

Torque item #17 to 100ft lbs.

Page 5

Torque item #26 to 100ft lbs.

Item #33 - Weld as shown, inline with rear lower a-arm shock tab face. Grind frame to bare metal before proceeding to weld. Placement of brake hardline may need to be adjusted on frame before welding.

Page 6


After installation is complete (shocks installed), adjust limit strap so that there is a 1/4" gap between the high misalignment spacer and the uniball cup on the upper control arm (see model below). Limit straps will stretch over time and will need to be adjusted periodically to prevent damage to shocks and uniball components.

TOTAL CHAOS Fabrication Inc. 159 North Maple St. Unit J Corona, CA 92880 951.737.9682

WWW.CHAOSFAB.COM

PROPRIETARY AND CONFIDENTIAL

THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF TOTAL CHAOS FABRICATION. ANY REPRODUCTION IN PART OR AS A WHOLE WITHOUT THE WRITTEN PERMISSION OF TOTAL CHAOS FABRICATION IS PROHIBITED.



PARTS LIST: 05+ TACOMA/4RUNNER/FJ LONG TRAVEL			
ITEM #	PART #	QTY.	ITEM DESCRIPTION
1	68601LH	1	CONTROL ARM, 05 TACO/4RUN/FJ UPPER LEFT
	68601RH	1	CONTROL ARM, 05 TACO/4RUN/FJ UPPER RIGHT
2	68602L	1	CONTROL ARM, 05 TACO/4RUN/FJ LOWER LEFT
	68602R	1	CONTROL ARM, 05 TACO/4RUN/FJ LOWER RIGHT
3	FK-JMX12T	4	HEIM, 3/4" x 3/4" RHT
4	99868	8	SPACER, UPPER CONTROL ARM HEIM
5	11373	4	JAM NUT, 3/4" HEIM
6	60684	2	BUSHING, URETHANE SHORT HALF
7	60292	6	BUSHING, URETHANE LONG HALF
8	69702	2	SLEEVE, LOWER ARM FRONT INNER
9	68603	2	SLEEVE, LOWER ARM REAR INNER
10	10025	2	BOLT, 1/2" x 2.50L FRONT SHOCK
11	10030	2	BOLT, 1/2" x 3.00L REAR SHOCK
12	11001	4	NUT, 1/2" NYLOCK
13	10710	6	BOLT, 3/8" X 1.00L SHOCK MOUNT
14	12011	6	WASHER, 3/8" SAE SHOCK MOUNT
15	10020	2	BOLT, 1/2" SOCKET HEAD FOX/KING SHOCK
	10025	2	BOLT, 1/2" x 2.50L SWAY A WAY SHOCK
16	58621K	2	SHOCK CIRCLE, BILLET, FOX/KING
17	10251	2	BOLT, 9/16" x 5.00L
18	12203	2	WASHER, 9/16" AN
19	100916TCF	2	SPACER, TOP UPPER ARM MISALIGNMENT
20	10034TCF	2	SPACER, BOTTOM UPPER ARM MISALIGNMENT
21	30004	2	SLEEVE, 9/16" TAPERED ADAPTER
22	12204	2	WASHER, 9/16" SAE
23	11202	2	NUT, 9/16" C-LOCK
24	12016	2	WASHER, 16MM LOCK, TACOMA
	12015	2	WASHER, 15MM LOCK, 4RUNNER &FJ
25	99016	2	EXTENSION, 16MM TIEROD, TACOMA
20	99015	2	EXTENSION, 15MM TIEROD, 4RUNNER & FJ
26	10342	2	BOLT, 3/4" x 4.25L SOCKET HEAD
27	10034C	2	SPACER, TOP LOWER ARM MISALIGNMENT
28	68614	2	ADAPTER, LOWER UNIBALL 2-BOLT FLANGE
29	10034T	2	SPACER, BOTTOM LOWER ARM MISALIGNMENT
30	0 V 3 V AV 3 V 1	2	
	12304		WASHER, 3/4" SAE
31	11302	2	NUT, 3/4" GRADE C LOCK
32	10616	4	BOLT, 16MM X 45MM FLANGE HEAD
33	69619	2	BRACKET, LIMIT STRAP CLEVIS, WELD ON
34	69618	2	CLEVIS, ADJUSTABLE LIMIT STRAP
35	69617	2	STRAP, 12" LIMIT
36	68610	2	SPACER, BUMPSTOP
37	97330	2	LINE, EXTENDED BRAKE
38	33301	4	CLIP, BRAKELINE RETAINING