



159 North Maple St. Unit J, CORONA CA 92880
P. 951-737-9682 F. 951-737-9006
WWW.CHAOSFAB.COM

Factory manual is recommended for removal and re-installation of all factory components.

1" Differential Spacer Installation Instructions PT# 87200

2007+ Tundra 4WD, 2005+ Tacoma 4wd, 03+ 4runner 4wd, 07+ FJ 4wd

1. Remove (2) front bolts from the front differential.
2. Retain the lower washer for installation of the TC spacer.
3. Drop the front of the differential down more than 1" (enough to allow the spacer room to slide in)
4. Slide the TC spacer in between the front differential and the frame.
5. Insert the new bolts supplied with the TC spacer including the factory lower washer.
6. Thread on the new washer and lock nut to the top side of the frame rail.
7. Tighten both bolts.



159 North Maple St. Unit J, CORONA CA 92880
P. 951-737-9682 F. 951-737-9006
WWW.CHAOSFAB.COM

Factory manual is recommended for removal and re-installation of all factory components.

1" Differential Spacer Installation Instructions PT# 87200

2007+ Tundra 4WD, 2005+ Tacoma 4wd, 03+ 4runner 4wd, 07+ FJ 4wd

1. Remove (2) front bolts from the front differential.
2. Retain the lower washer for installation of the TC spacer.
3. Drop the front of the differential down more than 1" (enough to allow the spacer room to slide in)
4. Slide the TC spacer in between the front differential and the frame.
5. Insert the new bolts supplied with the TC spacer including the factory lower washer.
6. Thread on the new washer and lock nut to the top side of the frame rail.
7. Tighten both bolts.



159 North Maple St. Unit J, CORONA CA 92880
P. 951-737-9682 F. 951-737-9006
WWW.CHAOSFAB.COM

Factory manual is recommended for removal and re-installation of all factory components.

1" Differential Spacer Installation Instructions PT# 87200

2007+ Tundra 4WD, 2005+ Tacoma 4wd, 03+ 4runner 4wd, 07+ FJ 4wd

1. Remove (2) front bolts from the front differential.
2. Retain the lower washer for installation of the TC spacer.
3. Drop the front of the differential down more than 1" (enough to allow the spacer room to slide in)
4. Slide the TC spacer in between the front differential and the frame.
5. Insert the new bolts supplied with the TC spacer including the factory lower washer.
6. Thread on the new washer and lock nut to the top side of the frame rail.
7. Tighten both bolts.