

1" Differential Spacer Installation Instructions PT# 96200
96-04 4WD Tacoma, 96-02 4-Runner & 00-06 Tundra 4WD

1. Remove (2) front bolts from the front differential.
2. Retain the lower washer for installation of the TC spacer.
3. Drop the front of the differential down more than 1" (enough to allow the spacer room to slide in)
4. Slide the TC spacer in between the front differential and the frame.
5. Insert the new bolts supplied with the TC spacer including the factory lower washer.
6. Thread on the new washer and lock nut to the top side of the frame rail.
7. Tighten both bolts.

Note: Factory skid plate may be re-installed, additional hardware/spacers may be required. The skid will touch the heads of the longer 9/16" bolts supplied with this kit.

